

N1F-A6.5US

User Manual

• Please read this user manual carefully before installation and use.

State

• Unauthorized reproduction and plagiarism are prohibited. • This information is subject to change without notice.

Contents

1. Information on this manual	ı
1.1 Scope	1
1.2 Target Group	1
1.3 Safety instructions 1	1
1.4 Introduction 2	2
1.5 Product Features 3	3
2. Product Overview	' +
3. Installation 5	5
3.1 Unpacking and Inspection 5	5
3.2 Preparation 5	5
3.3 Mounting the Unit 5	5
3.4 Lead-acid Battery Connection	5
3.5 Lithium Battery Connection 7	7
3.6 Lithium battery communication and setting	3
3.7 LCD setting 9	7
3.8 Communicating with battery BMS in parallel system 10)
3.9 AC Input/Output Connection 10)
3.10 PV Connection	2
3.11 Final Assembly 14	+
3.12 Starting inverter 14	' +
4. OPERATION 15	5
4.1 Power ON/OFF 15	5
4.2 Operation and Display Panel 15	5
4.3 Setup parameters description)
5. Operating Mode Description	3
5.1 Charging mode 28	3
5.2 AC output mode	7

6. Battery type parameters 31
6.1、For Lead-acid Battery 31
6.2、For Lithium Batter 32
7. Communication 33
7.1、Overview 33
7.2、USB communication port 33
7.3、RS485 communication port 33
7.4、Dry contact port
7.5、Parallel communication function (parallel operation only) · · · · 34
7.6、Current sharing detection function (parallel operation only)
8. Parallel installation and wiring 35
8.1、Introduction 35
8.2、Precautions for connecting the parallel connecting lines 35
8.3、Schematic diagram of parallel connection in single phase 37
8.4. Schematic diagram of parallel connection in spilit phase $\hdots 40$
8.5、Schematic diagram of parallel connection in single phase 46
9. Failure codes and countermeasures 51
9.1、Fault code 51
9.2、Trouble shooting 55
10. Protection and Maintenance 57
10.1、Protections provided 57
10.2、Maintenance 55
11. Technical parameters 60

1. Information on this manual

This manual describes the assembly, installation, operation and troubleshooting of this unit. Please read this manual carefully before installations and operations. Please keep this manual for future use.

1.1、Scope

This manual provides safety and installation guidance as well as information about tools and wiring.

1.2 Target Group

This document is intended for qualified persons and end users. Tasks that do not require any particular qualification can also be performed by end users. Qualified persons must have the following skills:

- 1. Knowledge of how an inverter works and was operated.
- 2. Training in how to deal with the dangers and risks associated with installing and using electrical devices and installations.
- 3. Training in the installation and commissioning of electrical devices and installations.
- 4. Knowledge of the applicable standards and directives.
- 5. Knowledge of and compliance with this document and all safety information.

1.3 Safety Instructions


- 1. Before using the unit, read all instructions and cautionary marking on the unit, the batteries and all appropriate sections of this manual. The company has the right not to quality assurance, if not according to the instructions of this manual for installation and cause equipment damage.
- 2. Please be clear which kind of battery system you want, lithium battery system or lead-acid battery system, if you choose the wrong system, energy storage system can't work normally.
- 3. Do not disassemble the unit. Take it to a qualified service center when service or repair is required. Incorrect re-assembly may result in a risk of electric shock or fire.
- 4. All the operation and connection please professional electrical or mechanical engineer. All the electrical installation must comply with the local electrical safety standards.
- 5、CAUTION-To reduce risk of injury, charge only deep-cycle lead-acid type rechargeable

batteries and lithium batteries. Other types of batteries may burst, causing personal injury and damage.

- 6. To reduce risk of electric shock, disconnect all wirings before attempting any maintenance or cleaning. Turning off the unit will not reduce this risk.
- 7. For optimum operation of this inverter, please follow required spec to select appropriate cable size. It's very important to correctly operate this inverter.
- 8. GROUNDING INSTRUCTIONS -This inverter should be connected to a permanent grounded wiring system. Be sure to comply with local requirements and regulation to install this inverter.

- 9 NEVER cause AC output and DC input short circuited. Do NOT connect to the mains when DC input short circuits.
- 10. Do not install the inverter in harsh environments such as moist, oily, flammable or explosive, or heavily dusty areas.
- 11. Warning!! Only qualified maintenance personnel can repair this equipment. If the fault persists after troubleshooting according to the troubleshooting table, take this inverter/charger back to your local dealer or service center for repair.
- 12. Do not reverse polarity of the battery input; otherwise, the device may be damaged or unpredictable risks may occur.
- 13. Make sure the inverter is completely assembled, before the operation.
- 14. Necessary to confirm that the inverter AC output power is the only input device for load, and it is forbidden to use it in parallel with other input AC power to avoid damage.
- 15. Recommended to attach proper fuse or circuit breaker to the outside of the inverter.

1.4. Introdugction



The figure below shows the system application scenario of this product. Specific system wiring method depends on the actual application scenario. A complete system consists of the following parts:


- 1. **PV String:** convert light energy into DC power, and charge the battery through the inverter, or directly invert into AC power to drive the load.
- 2. **Mains or generator:** connected at the AC input, to power the load while charging the battery. If the mains or generator is not connected, the system can also operate normally, and the load is powered by the battery and PV module.
- 3. **Battery:** According to the energy storage and energy release function of the system requirements. Support lithium battery and lead acid battery (set setup).
- 4. **Household load:** allow connection of various household and office loads, including refrigerators, lamps, TVs, fans and air conditioners.
- 5. **Hybrid solar charge inverter:** the energy conversion unit of the whole system.

6. WiFi or GPRS: can monitor system permissions remotely.

1.5 Product Features

- 1. It has the function of sectional charge and discharge.
- 2. Allowing access of lead-acid battery and lithium battery.
- 3. Anti-countercurrent grid-connected function (photovoltaic hybrid power supply), grid-connected mode can be set.
- 4. It can be used without battery. Solar and utility grid can power loads at the same time.
- 5. With dual activation function of lithium battery, it can be triggered by any power supply of the mains/photovoltaic.
- 6. Power saving mode available to reduce no-load loss.
- 7. Available in four charging modes: Only Solar, Mains Priority, Solar Priority and Mains & Solar hybrid charging.
- 8. Two output modes: mains bypass and inverter output; uninterrupted power supply.
- 9. Complete protections, including over voltage and under voltage protection, overload protection, reverse protection, etc $,360^{\circ}$ all-round protection with a number of protection functions.
- 10. ON/OFF rocker switch for AC output control.
- 11. Full digital voltage and current double closed loop control, advanced SPWM technology, output of pure sine wave.
- 12. Advanced MPPT technology with an efficiency of 99.9%.
- 13. Intelligent variable speed fan to efficiently dissipate heat and extend system life.

2. Product Overview



1)	AC input port	8	USB communication port
2	AC output port	9	Parallel communication port (parallel module only)
3	WiFi Port (Optional)	10	Current sharing port (parallel module only)
4	ON/OFF rocker switch	11)	RS485-1 communication port
(5)	PV input port	12)	CAN/RS485-2 communication port
6	Battery port	13)	Dry junction port
7	Ground screw hole	14)	Overload protector

3. Installation

3.1. Unpacking and Inspection

Before installation, please inspect the unit. Be sure that nothing inside the package is damaged. You should have received the following items in the package:

The unit x 1

User manual x 1

Ring terminal x 2

3.2、Preparation

Before connecting all wiring, please take off bottom cover by removing four screws as shown below.



3.3 Mounting the Unit

Consider the follonwing points before selecting where to install:

Do not install the inverter on fammable building materials.


Mount on a sturdy surface.

Install this inverter at eye level in order to allon the LCD display to be read at all times.


The ambient temperature should be between 10* cand 55*C to ensure optimal operation.

The recommended installation position is to beadhered to the wall vertically.

Be sure to keep other objects and surfaces as shon inthe right diagram to guarantee sufficient heat dissipationand to have enough space for removing wires.







Install the unit by screwing four screws. It's recommended to use M4 or M5 screws.

3.4 Lead-acid Battery Connection

User can choose proper capacity lead acid battery with a nominal voltage at 48V. Also, you need to choose battery type as "GEL (default) , SLD or FLD".


CAUTION: For safety operation and regulation compliance, It's requested to install a separate DC over-current protector or disconnect device between battery and inverter. It may not be requested to have a disconnect device in some applications, however, It's still requested to have over-current protection installed. Please refer to typical amperage in below table as required fuse or breaker size. **Ring terminal:**

Ring terminal:

WARNING! All wiring must be performed by a qualified person.

WARNING! It's very important for system safety and efficient operation to use appropriate cable for battery connection. To reduce risk of injury, please use the proper recommended cable and terminal size as below.

iding terrimian.



Recommended battery cable and terminal size:


Models	Wire Size	Rated battery discharge current	Maximum charging current	Recommended air switch or circuit breaker type	Torque value
N1F-A6.5US	33.6mm²/2AWG	153A	150A	2P—160A	2-3Nm

Note: For lead acid battery, the recommended charge current is 0.2C(C→battery capacity)

Please follow below steps to implement battery connection:

- 1. Assemble battery ring terminal based on recommended battery cable and terminal size.
- 2. Connect all battery packs as units requires. It's suggested to connect at least 200Ah capacity battery.
- 3. Insert the ring terminal of battery cable flatly into battery connector of inverter and make sure the

bolts are tightened with torque of 2Nm. Make sure polarity at both the battery and the inverter/charge is correctly connected and ring terminals are tightly screwed to the battery terminals.





WARNING: Shock Hazard

Installation must be performed with care due to high battery voltage in series.



CAUTION!! Do not place anything between the flat part of the inverter terminal and the ring terminal. Otherwise, overheating may occur.

 $\textbf{CAUTION!!} \ \ \text{Do not apply anti-oxidant substance on the terminals before terminals are connected tightly.}$

CAUTION!! Before making the final DC connection or closing DC breaker/disconnector, be sure positive (+) must be connected to positive (+) and negative (-) must be connected to negative.


3.5. Lithium Battery Connection

If choosing lithium battery for this inverter, you are allowed to use the lithium battery only which we have configured. There're two connectors on the lithium battery, RJ45 port of BMS and powercable.

Please follow below steps to implement lithium battery connection:

- 1. Assemble battery ring terminal based on recommended battery cable and terminal size (same as Lead acid, see section Lead-acid Battery connection for details).
- 2. Insert the ring terminal of battery cable flatly into battery connector of inverter and make sure the bolts are tightened with torque of 2–3Nm. Make sure polarity at both the battery and the inverter/charge is correctly connected and ring terminals are tightly screwed to the battery terminals.

- 3. Connect the end of RJ45 of battery to BMS communication port(RS485-2/CAN) of inverter.
- 4、The other end of RJ45 insert to battery communication port(RS485).




Note: If choosing lithium battery, make sure to connect the BMS communication cable between the battery and the inverter. See Section 3.7 for other Settings.

3.6. Lithium battery communication and setting

Connect the end of RJ45 of battery to BMS communication port of inverter. Make sure the lithium battery BMS port connects to the inverter is Pin to Pin, the inverter BMS (RS485-2/CAN) port pin and RS485-1 port pin assignment shown as below:

No.	BMS port (RS485-2/CAN)	RS485-1 port (Reserve)
1	RS485-A RS485-A	
2	RS485-B	RS485-B
3		
4	CAN-H	
5	CAN-L	
6		
7	5V	5V
8	GND	GND



3.7, LCD setting


When connecting a lithium battery BMS, match the battery list parameters in section 6 of the inverter according to the battery pack specifications, and set the battery type to the closest one of "LF14/LF15/LF16/ N13/N14" in the inverter [11] Settings. At the same time, after setting the battery type in parameter name [11], switch to parameter name [23] to select the communication mode, and finally switch to [24] to select the corresponding BMS communication protocol.

		[11]USE	User-defined; all battery parameters can be set.
	Battery type1	[11]SLd	Sealed lead-acid battery; constant-voltage charge voltage: 57.6V, floating charge voltage: 55.2V.
11		[11]FLd	Vented lead-acid battery; constant-voltage charge voltage: 58.4V, floating charge voltage: 55.2V.
		[11]GEL	Colloidal lead-acid battery; constant-voltage charge voltage: 56.8V, floating charge voltage: 55.2V
		[11]LF14/LF15/ LF16 default	Lithium iron phosphate battery LF14/LF15/LF16,corresponding to 14 strings,15strings and16stringsof lithium
			ironphosphatebattery;for16strings, defaultconstant-voltagechargevoltageis 56.8V;for15strings,default constant-voltagechargevoltageis53.2V;for 14strings,defaultconstant-voltagecharge voltageis49.2V;allowadjustable.
		[11]N13/N14	Ternarylithiumbattery; which is adjustable. The default constant voltage charging voltage of N13 is 53.2 V, and the default constant voltage charging voltage of N14 series is 57.6 V.

23	RS485-2/CAN communication	[23]DISdefault	RS485-2 Disable the BMS communication. However, our PC and remote monitoring protocol can continue to be used		
		[23]RS485	RS485-2 port for BMS communication		
24	BMS protocol	When the setting Program [23] is RS485, the corresponding lithium battery manufacturer brand needs to be selected for communication PLN=PYLONTECH,PCE=PACE,GXU=GOTION,DAQ, AOG=ALLGRAND,OLT=OLITER,XWD=SUNWODA,CFE,MIT=F ESS,VOL=WEELAND			
24	Settings				

3.8. Communicating with battery BMS in parallel system

If need to use communicate with BMS in a parallel system, you should make sure to connect the BMS communication cable between the battery and one inverter of the parallel system. It's recommended to connect to the master inverter of the parallel system.



3.9、AC Input/Output Connection

CAUTION!! Before connecting to AC input power source, please install a separate AC breaker between inverter and AC input power source. This will ensure the inverter can be securely disconnected during maintenance and fully protected from over current of AC input.

CAUTION!! Input "IN" and output "OUT" can not be connected to the reverse.

WARNING! All wiring must be performed by a qualified personnel.

WARNING! It's very important for system safety and efficient operation to use appropriate cable for AC input connection. To reduce risk of injury, please use the proper recommended cable size as below.

Suggested cable requirement for AC wires:

Models	Recommended AC input wiring diameter	Maximum bypass input current	Recommended air switch or circuit breaker type	Torque Value
N1F-A6.5US	10.5mm²/7AWG	60A	2P—63A	1.2-1.6Nm

Models	Recommended AC output wiring diameter	Maximum bypass output current	Recommended air switch or circuit breaker type	Torque Value
N1F-A6.5US	10.5mm²/7AWG	60A	2P—63A	1.2-1.6Nm

Please follow below steps to implement AC input/output connection:


- 1、Before making AC input/output connection, be sure to open DC protector or disconnector first.
- 2. Remove insulation sleeve 10mm for eight conductors. And shorten phase L and neutral conductor N 3mm.
- 3、Insert AC input wires according to polarities indicated on terminal block and tighten the terminal screws. Be sure to connect PE

 protective conductor first.

•	→Ground (yellow-green)
	L→LINE(brownorblack)
	N→Neutral(blue)
\wedge	WARNING: Be sure that AC power source is disconnected before attempting to hardwire it to the unit

4. Then, insert AC output wires according to polarities indicated on terminal block and tighten terminal screws. Be sure to connect PE • protective conductor first.

•	→Ground (yellow-green)
	L→LINE(brownorblack)
	N→Neutral(blue)



5. Make sure the wires are securely connected.

CAUTION: Important

Be sure to connect AC wires with correct polarity. If L and N wires are connected reversely, it may cause utility short-circuited when these inverters are worked in parallel operation.

CAUTION: Appliances such as air conditioner are required at least 2~3 minutes to restart because it's required to have enough time to balance refrigerant gas inside of circuits. If a power shortage occurs and recovers in a short time, it will cause damage to your connected appliances. To prevent this kind of damage, please check with manufacturer of air conditioner that if it's equipped with time-delay function before installation. Otherwise, this off grid solar inverter will trig overload fault and cut off output to protect your appliance but sometimes it still causes internal damage to the air conditioner.

3.10 PV Connection

CAUTION: Before connecting to PV modules, please install separately a DC circuit breaker between inverter and PV modules.

WARNING! All wiring must be performed by a qualified personnel.

WARNING! Do not connect one PV string to more than one inverter at the same time. Otherwise, it may cause damage to the inverter.

WARNING! It's very important for system safety and efficient operation to use appropriate cable for PV module connection. To reduce risk of injury, please use the proper recommended cable size as below

Models	Recommended PV wiring diameter	Maximum PV input current	Recommended air switch or circuit breaker type	Torque value
N1F-A6.5US	5.2mm²/10AWG	22A+22A	2P—32A	1.2-1.6Nm

PV Module Selection:


When selecting proper PV modules, please be sure to consider below parameters:

- 1. Open circuit Voltage (Voc) of PV not exceeds max. PV array open circuit voltage of inverter.
- 2. Open circuit Voltage (Voc) of PV array should be higher than start-up voltage.


INVERTER MODEL	N1F-A6.5US
Max. PV Array Open Circuit Voltage	300Vdc
Start-up Voltage	80Vdc
PV Array MPPT Voltage Range	90Vdc~260Vdc

Please follow below steps to implement PV module connection:

1. Remove insulation sleeve 10 mm for positive and negative conductors.




- 2. Check correct polarity of connection cable from PV modules and PV input connectors. Then, connect positive pole (+) of connection cable to positive pole (+) of PV input connector. Connect negative pole (-) of connection cable to negative pole (-) of PV input connector.
- 3. Make sure the wires were securely connected.



3.11、Final Assembly

After connecting all wiring, please put bottom cover back by screwing four screws as shown below.



3.12 Starting inverter

- Step 1: Close the battery circuit breaker.
- Step 2: Press the boat switch at the bottom of the inverter, and the screen and indicator light up, indicating that the inverter has been activated.
- Step 3: Close the circuit breakers of PV, AC input and AC output in turn.
- Step 4: Start the load one by one according to the order of power from small to large.


4. Operation

4.1. Power ON/OFF

Once the unit has been properly installed and the batteries are connected well, simply press On/Off switch (located on the button of the case) to turn on the unit.

4.2. Operation and Display Panel

The operation and display panel, shown in below chart, is on the front panel of the inverter. It includes three indicators and a LCD display, indicating the operating status and input/outputpower information



1.LCDdisplay

2.Statusindicator

3. Charging indicator

4.Faultindicator

5.Functionbuttons


Indicators introduction:

Indicators	Colors	Description
AC OUT	Cuan	Steady on: Mains output
AC OUT	Green	Flash: inverter output
0114805		Flash: Fast charging
CHARGE	Yellow	Steady on: Floating charge
FAULT	Red	Flash : Fault state

Operation buttons introduction:

Function buttons	Description
ESC	To exit setting mode
UP	Previous choice
DOWN	Next choice
ENTER	To confirm the selection insetting mode or enter setting mode

LCD screen introduction:



Icons	Functions	Icons	Functions
8	Indicates that the AC input terminal has been connected to the grid	523	Indicates that the inverter circuit is working
0	Indicates that the AC input mode in APL mode (wide voltage range)	BYPASS	Indicates that the machine is in the Mains Bypass mode
	Indicates that the PV input terminal has been connected to the solar panel	OVER LOAD	Indicates that the AC output is in an overload state
	Indicates that the machine has been connected to the battery: indicates that the remaining battery is 0%~24%; indicates that the remaining battery is 25%~49%; indicates that the remaining battery is	100%	Indicates the percentage of AC output loads: indicates that the load percentage is 0%~24%; indicates that the load percentage is 25%~49%, indicates that the load percentage is 50%~74%,
	50%~74%; indicates that the remaining battery is 75%~100%.		indicates that the load percentage is ≥75%
Li	Indicates that the battery type of the machine is a lithium battery		Indicates that the buzzer is not enabled
SLA	Indicates that the current battery type of the machine is a lead-acid battery	A	Indicates that the machine has an alarm
CHARGING	Indicates that the battery is in charging state	ERROR	Indicates that the machine is in a fault condition
7000	Indicates that the AC/PV charging circuit is working		Indicates that the machine is in setup mode

M	In parallel operation, this icon indicates that this inverter is the host, which is only valid in parallel mode.		
Parameters	display on the left side of	the screen: in	put parameters
(AC)	Indicates AC input		
PV	Indicates PV input		
123	Indicates the PV1 /PV 2 inpu	t	
INPUTBATTEVP. RIST STORY RIST STO	Display battery voltage, ba power, AC input voltage, A internal heat sink temperat	C input freque	ncy, PV input voltage,
Parameters	display on the right side o	of the screen: (Output parameters
OUTPUTBATTLOAD LYW VA VA SMS SMS	Indicates output voltage, output current, output active power, output apparent power, battery discharge current, software version; in setup mode, displays the set parameters under the currently set parameter item code		
Arrow disp	lay		
1)	Indicates the grid supplying power to the load	4	Indicates the charging circuit charging the battery terminal
2	Indicates grid supplying power to the charging circuit	(5)	Indicates the battery terminal supplying power to the inverter circuit
3	Indicates PV module supplying power to the charging circuit	6	Indicates the inverter circuit supplying power to the load
7	The arrow is not displayed		

Real-timedataviewingmethod

On the LCD main screen, press the "UP" and "DOWN" buttons to scroll through the real-time data of the machine.

Page	Parameters on the left side of the screen	Parameters in the middle of the screen	Parameters on the right side of the screen
1	Battery voltage		Output voltage
2	Battery voltage collected by BMS (It will be displayed only after BMS communication is normal)		Battery capacity rate obtained by BMS (It will be displayed only after BMS communication is normal)
3	Battery current		Battery output power
4	AC output load current	Fault code	Load active power
5	AC output frequency	r dant code	Load apparent power
6	AC input current		AC input voltage
7	AC input frequency		AC input apparent power
8	PV1 input voltage		PV1 input power
9	PV charger heatsink temperature		PV1 input current
10	PV2 input voltage		PV2 input power
11	PV charger heatsink temperature		PV2 input current
12	AC charge or battery discharge heatsink temperature	Fault code	Bus voltage
13	software version 1		software version 2
14	Model Battery Voltage Rating		Model Output voltage Rating
15	Model PV Voltage Rating		Model PV Current Rating
16	RS485 Address Number		Inverter parallel mode

4.3 Setup parameters description

Buttons operation instructions: Press the "SET" button to enter the setup menu and exit the setup menuAfter entering the setup menu, the parameter number [00] will flash. At this point, press the "Up" and "DOWN" buttons to select the code of parameter item to be set. Then, press the "ENT" button to enter theparameter editing mode, and the value of the parameter is flashing. Adjust the value of the parameterwith the "UP" and "DOWN" buttons. Finally, press the "ENT" button to complete the parameter editing andreturn to the parameter selection state.

Note:inparallelmode, all machines will synchronize the setting parameters of the host (the machine with "M" is displayed on the displays creen) before startup. After startup, the setting parameters of any machine will be synchronized to other machines in the system

Parameter no.	Parameter name	Settings	Description
00	Exit setting menu	[00] ESC	Exit the setup menu
		[01] PV	PV priority mode, switching to the Mains when the PV fails or the battery is lower than the set value of parameter [16].
		[01] GID (default)	Mains priority mode, switching to inverter only when the mains fails.
01	Output source priority	[01] BAT	Battery priority mode. Switch to mains power only when the battery is under voltage or lower than the setting value of parameter [16]; Switch to battery discharge only when the battery is fully charged or higher than the setting value of parameter [17].
		[01] HBR	Hybrid mode, you can set this mode through the [33] setting item.
02	AC output voltage setting	[02] 120V	Allow to set to 100Vac/105Vac/110Vac/120Vac, default 120V. AC output power = rated power*(Vset/120)
		[03] 50.0HZ	Bypass self-adaptation; when the mains is connected, it automatically
03	Output Frequency	[03] 60.0HZ	adapts to the mains frequency; when the mains is disconnected, the output frequency can be set through this menu. The default output frequency to 50Hz of the 120V.

Parameter no.	Parameter name	Settings	Description
		[04] UPS (default)	Narrow mains input voltage range of 120Vac machine: 90~140Vac; Frequency range: 47~55Hz (50Hz);57Hz ~ 65Hz (60Hz);
04	AC Input Voltage Range	[04] APL	Wide mains input voltage range of 120Vac machine: 90~140Vac; Frequency range: 47~ 55Hz (50Hz); 57Hz ~ 65Hz (60Hz);
		[04] GEN	Diesel generators input, need to set this mode, at this time: Narrow Ac input voltage range of 120Vac machine: 90~140Vac Frequency range: 40~ 70Hz
		[05] DIS (default)	Power saving mode disabled.
05	Power saving mode	[05] ENA	After the power saving mode is enabled, if the load is null or less than 25W, the inverter output is turned off after a delay for a certain period of time. When the load is more than 50W, the inverter automatic restart.
		[06] OSO	PV priority charging; only when the PV charging fails, the mains charging is started.
		[06] OUO	Mains priority charging; only when the mains charging fails, the PV charging is started.
06	Charger source priority	[06] SNU (default)	PV and Mains hybrid charging; PV charging is a priority, and when the PV energy is insufficient, the Mains charging supplements. When the PV energy is sufficient, the Mains charging stops. Note: Only when the Mains bypass output is loaded, the PV charging and the mains charging can work at the same time. When the inverter works, only the PV charging can be started. Only PV charging, with the Mains
		[06] NUC	charging not activated.
07	Max total charging current	[07] 80A (default)	Maximum total charging current setting. setting range:0~150A.

Parameter no.	Parameter name	Settings	Description
08	Max PV charger current	[08] 80A (default)	Max PV charger current. Setting range: 0~150A;
09	Max AC charger current	[09] 60A (default)	setting range: 0~120A
10	Battery fully charging current setting	[10] 3A (default)	When the battery type is lead-acid, when the battery voltage is greater than or equal to the floating charge value, and the charging current is less than the setting value, the battery is considered to be fully charged and the charging is stopped; If the battery type is lithium battery, when the battery voltage is greater than or equal to the constant voltage charging value and the charging current is less than the set value, the battery is considered to be fully charged and the charging is stopped.
		[11] USE	User-defined; all battery parameters can be set.
		[11] SLd	Sealed lead-acid battery; constant-voltage charge voltage: 57.6V, floating charge voltage: 55.2V.
		[11] FLd	Vented lead-acid battery; constant-voltage charge voltage: 58.4V, floating charge voltage: 55.2V.
11	Battery Type	[11] GEL	Colloidal lead-acid battery; constant-voltage charge voltage: 56.8V, floating charge voltage: 55.2V.
		[11] LF14/LF15/L F16 (default)	Lithium iron phosphate battery LF14/LF15/LF16, corresponding to 14strings ,15 strings and 16 strings of lithium iron phosphate battery; for 16 strings, default constant-voltage charge voltage is 56.8V; for 15 strings, default constant-voltage charge voltage is 53.2V; for 14 strings, default constant-voltage charge voltage is 49.2V; allow adjustable.

Parameter no.	Parameter name	Settings	Description
		[11] N13/N14	Ternary lithium battery; which is adjustable. The default constant voltage charging voltage of N13 is 53.2V, and the default constant voltage charging voltage of N14 series is 57.6V.
12	Battery boost charge voltage	[12] 57.6V (default)	Boost charge voltage setting; the setting range is 48V~58.8V, with step of 0.1V; it is valid for user-defined battery and lithium battery.
13	Battery floating charge voltage	[13] 55.2V (default)	Floating charge voltage, setting range: 48V~58.8V, step: 0.1V.
14	Battery boost charge time	[14] 120 (default)	Boost _h C arge maximum time setting, which means the maximum charging time to reach the set voltage of parameter [12] during constant-voltage charging. The setting range is 5min~900min, with a step of 5 minutes. It is valid for user-defined battery and lithium battery.
15	Battery recharge recovery point	[15] 52V (default)	After the battery is fully charged, the inverter stops charging, and restarts charging when the battery voltage is lower than the voltage value.
16	Battery Power to Utility Setpoint	[16] 46V (default)	When the parameter [01] =Bat, the battery voltage is lower than the set value, and the output is switched from the inverter to the mains. Setting range: 38V~57.2V.
17	Utility to Battery Power Setpoint	[17] 57.6V (default)	When the parameter [01] = Bat, the battery voltage is higher than the set value, and the output is switched from the mains to the inverter. Setting range: 48V~60V.
18	Battery under voltage alarm	[18] 44V (default)	Battery undervoltage alarm point; when the battery voltage is lower than the point, an undervoltage alarm is given (01 fault), and the output is not turned off; the setting range is 39V~56V, with a step of 0.1V.
19	Battery over discharge voltage (delay off)	[19] 42V (default)	Over-discharge voltage; when the battery voltage is lower than this judgment point, delay the time set by parameter [22] and turn off

Parameter no.	Parameter name	Settings	Description
			inverter output. Setting range is 38V~56V, with a step of 0.1V.
20	Battery over discharge voltage (immediately)	[20] 42V (default)	Battery discharge limit voltage; when the battery voltage is lower than the point, the output is turned off immediately (02 fault); the setting range is 38V~48.8V, with a step of 0.1V. It is valid for user-defined battery and lithium battery.
21	Battery voltage recovery point after over discharge protection (02 fault)	[21] 52V (default)	When the battery over discharge protection disconnects the inverter output, the battery voltage must be greater than this value to restore the inverter AC output.
22	Battery over discharge delay time	[22] 5S (default)	Over-discharge delay time; when the battery voltage is lower than the parameter [19], the inverter output will be turned off after the time set by this parameter is delayed. The setting range is 5S~120S, with a step of 5S.
23	RS485-2 /CAN communication	[23] DIS (default)	RS485-2 Disable the BMS communication. However, our PC and remote monitoring protocol can continue to be used.
		[23] RS485	RS485-2 port for BMS communication.
24	BMS protocol Settings	correspondin needs to be s PLN=PYLON DAQ, AOG=A	ting Program [23] is RS485, the g lithium battery manufacturer brand selected for communication IECH, PCE=PACE, GXU=GOTION, ALLGRAND, OLT=OLITER,
		XWD=SUNW VOL=WEELAI	ODA, CFE, MIT=FOXESS, ND

25	SOC discharge alarm (Optional when BMS is enabled)	[25] 15% (default)	After the BMS of the setting item [23] is enabled, the machine will alarm 07 if the battery capacity rate is lower than this value, and the alarm will be cleared if the battery capacity rate is higher than 5% of this value.
26	SOC switching mains (optional when BMS is enabled)	[26] 10% (default)	After the BMS of the setting item [23] is enabled, the machine will switch to the mains when the battery capacity rate is lower than
Parameter no.	Parameter name	Settings	Description
			this value and the mains power is available.
27	SOC switching inverter (optional when BMS is enabled)	[27] 100% (default)	After the BMS of the setting item [23] is enabled, it takes effect in battery priority mode. If the battery capacity rate is higher than this value, the machine will switch from the mains to the inverter mode.
28	SOC discharge cut off (optional when BMS is enabled)	[28] 5% (default)	After the BMS of the setting item [23] is enabled, if the battery capacity rate is lower than this value, the machine will report 08 fault and cut off the power supply or output.
29	SOC charging cut off (optional when BMS is enabled)	[29] 100% (default)	After the BMS of the setting item [23] is enabled, when the battery capacity rate is higher than this value, the inverter considers the battery to be full. If the battery priority mode is adopted at this time, the machine will switch the battery back from the mains.
30	Buzzer alarm	[30] DIS (default)	Alarm beep is enabled when the status of the main input source changes or the inverter fails.
		[30] ENA	Buzzer is silent


	AC output mode (can be set in the standby mode only)	[31] SIG (default)	When single inverter is used, the default is SIG mode.		
		[31] PAL	In parallel operation with single phase. Please refer to 8.3 Wiring Diagram.		
		[31] 3P1/3P2/3P 3	In split phase operation with three phase. Please refer to 8.4 Wiring Diagram.		
31		All connected P1-phase inverters are set to "3P1";			
		All connected P2-phase inverters are set to "3P2";			
		All connected P3-phase inverters are set to "3P3"; When the parameter [02] setting item=120: AC output line voltage difference is 120 degrees (P1-P2/P1-P3/P2-P3), each line voltage is 120*1.732= 208Vac; Each phase voltage is 120Vac (L1-N; L2-N; L3-N).			
32	RS485 ID setting	[32] 1 (default)	Parallel mode needs to be set in the range of 1-6, the ID cannot be repeated. When the power is first turned on, it will be automatically distributed. Single mode setting range 1-254.		
33	Mixed mode (available for some models, Hybrid mode available)	[33] GID	It is allowed to connect to the grid, and the surplus electricity is generated by the grid.		
		[33] LOD	Anti-countercurrent, self-use according to the load power, do not input current to the mains.		
34	N-PE connection switchover is enabled	[34] DIS (default)	Do not automatically connect the N wire to the PE wire under any working conditions.		
		[34] ENA	When there is no mains input off the grid, the neutral line automatically connects to the PE. When the bypass has mains input, the neutral line is automatically disconnected from the PE.		

Parameter no.	Parameter name	Settings	Description
35	Automatic battery activation	[35] DIS	When the battery is dormant or not connected, the PV or mains does not automatically activate the battery to turn on the battery output.
		[35] ENA (default)	When the battery is dormant or not connected, the PV or mains automatically activates the battery to turn on the battery output.


5. Operating Mode Description

5.1. Charging mode


1) PV priority: PV module will charge the battery preferentially, and the battery is charged by the Mains only when the PV system fails. During the day, solar energy is fully used to charge, while at night, it converts to the Mains. This can maintain battery level, and is ideal for areas where the grid is relatively stable and electricity price is relatively high.




2) Mains priority: The Mains supply is preferentially used to charge the battery. Only when the Mains fails, the PV charging can be activated.



3) Hybrid charging: PV and mains hybrid charging. PV MPPT charging is a priority, and when PV energy is insufficient, the mains supply supplements. When the PV energy is sufficient again, the mains stops charging. This is the fastest charging mode, suitable for the areas where power grid is unstable, providing sufficient backup power supply at any time.



4) Only Solar: Only PV charging, without Mains charging. This is the most energy-efficient way in which battery is charged only by solar panels, and is usually used in areas with good lighting conditions.




5.2 AC output mode

> PV priority mode:

Photovoltaics and batteries power the load, switch to mains supply when the PV charging fails. This mode maximizes the use of solar energy while maintaining battery power, suitable for use in the areas with relatively stable grid.


Power supply priority: Solar→Battery→Utility.



Mains priority mode:

Switch to inverter only when the mains fails (when there was mains power, switch to mains power for charging and power supply). Then, the unit is equivalent to a backup UPS, suitable for areas with unstable grid. Switching does not affect PV charging.

Power supply priority: Solar→Battery→Utility.



> Battery priority mode:

Switch to mains supply only when the battery discharge undervoltage is lower than the set point (16 setting item). When the charging battery is higher than the set point of (17 setting item), switch to the battery discharge mode. This can cycle the battery charge and discharge. This mode maximizes the use of DC power and is used in the area with stable grid. Switching does not affect PV charging.

Power supply priority: Solar→Battery→Utility.




> Hybird mode:

LOD: Inverter power generation energy only to the load (generation power < Load power). Note: mixed load, mains and photovoltaic are loaded together, photovoltaic is not enough to supplement the mains

GID: Inverter power generation energy directly connected to the grid (generation power may be greater than the load power).

Note: photovoltaic power generation is sufficient load power, excess grid-connected power **generation**



6. Battery type parameters

6.1 For Lead-acid Battery


Battery Type parameter	Sealed lead acid battery (SLD)	Colloidal lead acid battery (GEL)	Vented lead acid battery (FLD)	User-defined (User)		
Overvoltage disconnection voltage	60V	60V	60V	40~60V (Adjustable)		
Battery fully charged recovery point(setup item)	52V (Adjustable)	52V (Adjustable)	52V (Adjustable)	52V (Adjustable)		
Boost charge voltage	57.6V	56.8V 58.4V		40~60V (Adjustable)		
Floating charge voltage	55.2V	55.2V 55.2V		40~60V (Adjustable)		
Undervoltage alarm voltage(01 fault)	44V	44V	44V 44V			
Undervoltage alarm voltage recovery point(01 fault)	Undervoltage alarm voltage+0.8V					
Low voltage disconnection voltage(02 fault)	42V 42V		42V	40~60V (Adjustable)		
Low voltage disconnection voltage recovery point (02 fault)	52V (Adjustable)	52V 52V (Adjustable)		52V (Adjustable)		
Discharge limit voltage	40V	40V	40V	40~60V (Adjustable)		
Over-discharge delay time	5s	5s	5s	1~30V (Adjustable)		
Boost charge duration	120 minutes	120 minutes	120 minutes	10 ~ 600 minutes (Adjustable)		

6.2 For Lithium Batter

Battery type Parameters	Ternary lithium battery (N13)	Ternary lithium battery (N14)	Lithium iron phosphate battery (LF16)	Lithium iron phosph ate battery (LF15)	Lithium iron phosphate battery (LF14)
Overvoltage disconnection voltage	60V	60V	60V	60V	60V
Battery fully charged recovery point(setup item 15)	50.4V (Adjustable)	54.8V (Adjustable)	53.6V (Adjustable)	50.4V (Adjusta ble)	47.6V (Adjustable)
Boost charge voltage	53.2V (Adjustable)	57.6V (Adjustable)	56.8V (Adjustable)	53.2V (Adjusta ble)	49.2V (Adjustable)
Floating charge voltage	53.2V (Adjustable)	57.6V (Adjustable)	56.8V (Adjustable)	53.2V (Adjusta ble)	49.2 (Adjustable)
Undervoltage alarm voltage(01 fault)	43.6V (Adjustable)	46.8V (Adjustable)	49.6V (Adjustable)	46.4V (Adjusta ble)	43.2V (Adjustable)
Undervoltage alarm voltage recovery point(01 fault)	Undervoltage alarm voltage+0.8V				
Low voltage disconnection voltage(04 fault)	38.8V (Adjustable)	42V (Adjustable)	48.8V (Adjustable)	45.6V (Adjusta ble)	42V (Adjustable)
Low voltage disconnection voltage recovery point (04 fault)(setup item 35)	46V (Adjustable)	49.6V (Adjustable)	52.8V (Adjustable)	49.6V (Adjusta ble)	46V (Adjustable)
Discharge limit voltage	36.4V	39.2V	46.4V	43.6V	40.8V
Over-discharge delay time	30s (Adjustable)	30s (Adjustable)	30s (Adjustable)	30s (Adjusta ble)	30s (Adjustable)
Boost charge duration	120 minutes (Adjustable)	120 minutes (Adjustable)	120 minutes (Adjustable)	120 minutes (Adjusta ble)	120 minutes (Adjustable)

7. Communication

7.1. Overview



1	Dry contact port	2	CAN/RS485-2 port	3	RS485-1 port
4	USB-B port	5	Parallel communication port	6	Current sharing port

7.2. USB communication port

This is a USB communication port, which can be used for USB communication with the optional PC host software. To use this port, you should install the corresponding "USB to serial chip CH340T driver" in the computer.



7.3、RS485 communication port

This port is an RS485 communication port. There are two RS485 ports: RS485-1 and RS485-2.

The RS485 communication port has two functions:




- 1) RS485 communication with the lithium battery BMS directly via the RS485-2 port (custom required);
- 2) RS485-1/RS485-2 also allows direct connection with the optional RS485 to WiFi/GPRS communication module developed by our company through this port. After the module is selected, you can connect the inverter through the mobile phone APP, on which you can view the operating parameters and status of the device. (Note: RS485-2 can only be used when BMS is not enabled).

7.4. Dry contact port

N-NO-NC function:

Working principle: This dry node can control the ON/OFF of the diesel generator.

- 1) Normally, NC-N point is connected and the NO-N point is disconnected;
- 2) When the battery voltage reaches the low voltage disconnection point, the relay coil is energized, the NO-N point is connected while NC-N point is disconnected. At this point, NO-N point can drive resistive loads specifications: 125VAC/1A, 230VAC/1A or 30VDC/1A.



IP-GND function:

Optional function, not standard function;

Working principle: This dry node can control the AC output power ON/OFF of the inverter.

- 1) IP-GND is disconnected→AC output ON;
- 2) IP-GND is connected → AC output OFF;

(CT+)-GND function:

Optional function, not standard function;

Working principle: By sampling the input line current, self-use function is realized. But need to use our configuration of

7.5. Parallel communication function (parallel operation only)

- a) This port is used for parallel communication, through which the parallel modules can communicate with each other.
- b) Each inverter has two DB15 ports, one for the male connector and the other for the female connector.
- c) When connecting, make sure to connect the male connector of the inverter with the female connector of the inverter to be paralleled, or connect the female connector of the inverter to the male connector of the inverter to be paralleled.
- d) Do not connect the male connector of the inverter to its female connector.

Female connector



Male connector



7.6. Parallel communication function (parallel operation only)

a) This port is used for current sharing detection, through which the current sharing of the parallel modules can be detected (parallel operation only). b) Each inverter has two current sharing detection ports, which are connected in parallel. When it is connected to other models to be paralleled, either port can be connected for convenience. There is no special mandatory wiring requirements.



8. Parallel installation and wiring

8.1. Introduction

- 1. Maximum six inverters can be used for parallel operation. Only "BG" models can support parallel.
- 2. When using the parallel operation function, the following connecting lines (package accessories) shall be firmly and reliably connected:

Parallel communication line*1: Current sharing detection line*1:





8.2. Precautions for connecting the parallel connecting lines

Warning: 👍

1. Battery wiring:

Parallel connection in single or spilit phase: Ensure that all all-in-one solar charger inverters are connected to the same battery, with BAT + connected to BAT + , BAT - connected to BAT -, and that the connection is correct with the same wiring length and line diameter before power on and start-up, so as to avoid the abnormal operation of parallel system output caused by wrong connection.

2、AC OUT wiring:

Parallel connection in single phase: Ensure L-to-L, N-to-N and PE-to-PE connection for all all-in-one solar charger inverters, and that the connection is correct with the same wiring length and line diameter before power on and start-up, so as to avoid the abnormal operation of parallel system output caused by wrong connection. For specific wiring, please refer to 8.3 Wiring Diagram

Parallel connection in single phase: Ensure N-to-N and PE-to-PE connection for all all-in-one solar charger inverters. The L lines of all inverters connected to the same phase need to be connected together. But L lines of different phases cannot be joined together. Other connection precautions are the same as parallel connection in single phase. For specific wiring, please refer to 8.4 Wiring Diagram.

3、AC IN wiring:

Parallel connection in single phase: Ensure L-to-L, N-to-N and PE-to-PE connection for all all-in-one solar charger inverters, and that the connection is correct with the same wiring length and line diameter before power on and start-up, so as to avoid the abnormal operation of parallel system output caused by wrong connection. Meanwhile, it is not allowed to have multiple different. AC source inputs to avoid damage to the external equipment of the inverter. The consistency and uniqueness of AC source input shall be ensured. For specific wiring, please refer to 8.3 Wiring Diagram.

Parallel connection in single phase: Ensure N-to-N and PE-to-PE connection for all all-in-one solar charger inverters. The L lines of all inverters connected to the same phase need to be connected together. But L lines of different phases cannot be joined together. Other connection precautions are the same as parallel connection in single phase. For specific wiring, please refer to 8.4 Wiring Diagram. AC source inputs to avoid damage to the external equipment of the inverter. The consistency and uniqueness of AC source input shall be ensured. For specific wiring, please refer to 8.3 Wiring Diagram.

4. Wiring of parallel communication line:

Parallel connection in single or spilit phase: Our company's parallel communication line is a DB15 standard computer cable with shielding function. Ensure the "one-in-one-out" rule when connecting each inverter, that is, connect the male connector (out) of this inverter with the female connector (in) of the inverter to be paralleled. Do not connect the male connector of the inverter to its female connector. In addition, make sure to tighten the parallel communication line of each inverter with self-contained end screws of DB15 to avoid the abnormal operation or damage of the system output caused by the falling off or poor contact of the parallel communication line. AC source inputs to avoid damage to the external equipment of the inverter. The consistency and uniqueness of AC source input shall be ensured. For specific wiring, please refer to 8.3 Wiring Diagram.

5. Wiring of current sharing detection line:


Parallel connection in single or spilit phase: Our company's parallel communication line is a DB15 standard computer cable with shielding function. Ensure the "one-in-one-out" rule when connecting each inverter, that is, connect the male connector (out) of this inverter with the female connector (in) of the inverter to be paralleled. Do not connect the male connector of the inverter to its female connector. In addition, make sure to tighten the parallel communication line of each inverter with self-contained end screws of DB15 to avoid the abnormal operation or damage of the system output caused by the falling off or poor contact of the parallel communication line. AC source inputs to avoid damage to the external equipment of the inverter. The consistency and uniqueness of AC source input shall be ensured. For specific wiring, please refer to 8.3 Wiring Diagram.

Parallel connection in single or spilit phase: The current sharing detection lines of all inverters connected to the same phase need to be connected together. But the current sharing detection lines of different phases cannot be joined together. Other connection precautions are the same as parallel connection in single phase. For specific wiring, please refer to 8.4 Wiring Diagram.


- **6.** Before or after connecting the system, please carefully refer to the following system wiring diagram to ensure that all wiring is correct and reliable before power on.
- **7.** After the system is wired, powered on and in normal operation, if a new inverter needs to be connected, make sure to disconnect the battery input, PV input, AC input and AC output, and that all all-in-one solar charger inverters are powered off before reconnecting into the system.

8.3、Schematic diagram of parallel connection in single phase


1. The parallel communication line and current sharing detection line of the all-in-one solar charger inverter need to be locked with screws after connecting. The schematic diagram is as follows:




- 2. In case of parallel operation with multiple inverters, the schematic diagram of parallel connection is as follows:
- a) Three all-in-one solar charger inverters of the system connected in parallel:



b) Four all-in-one solar charger inverters of the system connected in parallel:




c) Five all-in-one solar charger inverters of the system connected in parallel:





d) Six all-in-one solar charger inverters of the system connected in parallel:




8.4. Schematic diagram of parallel connection in single phase


- 1. The parallel communication line and current sharing detection line of the all-in-one solar charger inverter need to be locked with screws after connecting. The schematic diagram is as follows:
- 2. In case of parallel operation with multiple inverters, the schematic diagram of parallel connection is as follows:


Parallel Operation in three phase:

a) Three all-in-one solar charger inverters of the system connected in three phase: 1+1+1 system:





b) Four all-in-one solar charger inverters of the system connected in three phase: 2+1 system:







c) Four all-in-one solar charger inverters of the system connected in two phase:3+1 system:






2+2 system:







d) Five all-in-one solar charger inverters of the system connected in two phase:

4+1 system:







3+2 system:




e) Six all-in-one solar charger inverters of the system connected in two phase: 5+1 system:







4+2 system:





3+3 system:





8.5. Schematic diagram of parallel connection in spilit phase




- 1. The parallel communication line and current sharing detection line of the all-in-one solar charger inverter need to be locked with screws after connecting. The schematic diagram is as follows:
- 2. In case of parallel operation with multiple inverters, the schematic diagram of parallel connection is as follows:


Parallel Operation in three phase:

a) Three all-in-one solar charger inverters of the system connected in three phase:













b) Four all-in-one solar charger inverters of the system connected in three phase: 2+1+1 system:






c) Five all-in-one solar charger inverters of the system connected in three phase:2+2+1 system:







3+1+1 system:




d) Six all-in-one solar charger inverters of the system connected in three phase:


2+2+2 system:






3+2+1 system:







Note:

- 1) Before starting up and running, please check whether the connection was correct to avoid any abnormalities in the system
- 2) All wiring must be fixed and reliable to avoid wire drop during use.
- 3) When the AC output is wired to the load, it shall be properly wired according to the requirements of the electrical load equipment to avoid damage to the load equipment
- 4) Settings [02] need to be set consistently or only for the host. When the machine is running, the voltage set by the host shall prevail, and the master will force the rewrite of the other slave machines to keep the same set. Only can be set in the standby mode.
- 5) When using parallel or spilit phase separation function, the [31] setting items need to be set accordingly.
- 6) When the phase sequence is set [02] [31] on the screen, the setting one is turned on to set, and the other machines are turned off. One by one set. Finally, power off and start up again.
- 7) After the system runs, the output voltage is measured correctly, and then the load setting is connected

9. Failure codes and countermeasures

9.1、Fault code

Fault code	Fault name	Whether it affects the output or not	Description
[01]	Battery under voltage warning	No	If the battery voltage is lower than [18], the battery is in the undervoltage state.
[02]	Battery under voltage protection	Yes	When the battery voltage was low, turn off the output to stop the battery discharge protection.
[03]	Average battery discharge current over current protection	Yes	If the average battery discharge current exceeds the maximum input battery current for 1 minute, turn off the output to stop the battery discharge protection.
[04]	Instantaneous battery discharge over current protection	Yes	If the instantaneous value of the battery discharge current is greater than the maximum instantaneous value of the device, turn off the output to stop the battery discharge protection.
[05]	Battery not connected	Yes	Battery not connected warning.
[06]	Battery over voltage	Yes	When the selected battery type or set battery voltage is exceeded, turn off the output to stop the battery charging protection.
[07]	BMS low battery talarm	No	BMS alarm low battery (Set BMS enablement to work)
[80]	BMS low battery protection	Yes	The BMS battery capacity rate is low. Disable the output to stop the battery discharge protection. (Set BMS enablement to work)
[09]	BMS low battery protection	Yes	If the mains is overloaded, turn off the AC output and stop the mains charging.

[10]	Battery outputr overload protection	Yes	If the battery discharge inverter is overloaded, turn off AC output and stop battery discharge protection.
[11]	Battery inverter output short circuit	Yes	If the AC output of the battery inverter discharge is short circuiting, turn off the AC output and stop the battery discharge protection.
[12]	The AC output of the battery inverter over circuit	Yes	If the AC output of the battery inverter discharge is over circuit, turn off the AC output and stop the battery discharge protection.
[13]	The DC component of the battery inverter voltage is abnormal	Yes	If the DC component of the battery inverter voltage is abnormal, turn off the AC output and stop the battery discharge protection.
[14]	Bus over voltage software sampling protection	Yes	Internal battery boost, boost bus voltage overvoltage software protection, turn off AC output and charge.
[15]	Bus over voltage hardware sampling protection	Yes	Internal battery boost, boost bus voltage overvoltage hardware protection, turn off AC output output and charge
[16]	Bus under voltage protection	Yes	Internal battery boost, boost bus voltage undervoltage protection, turn off AC output output and charge.
[17]	Bus short circuit protection	Yes	Internal battery boost, boost bus voltage short-circuit protection, turn off AC output output and charge.
[18]	The PV input voltage is over voltage	Yes	The solar input voltage exceeds the maximum allowable input voltage protection.
[19]	The PV current software is overcurrent	-	-
[20]	PV over current protection	No	Solar charging overcurrent hardware protection, turn off solar charging.
[21]	The PV insulation impedance is low	-	-

[22]	The PV heat sink is overheated. Procedure	No	If the temperature of the solar charging radiator is too high, turn off the solar charging.
[23]	The AC heat sink is overheated. Procedure	Yes	If the temperature of the heat sink is too high, turn off the AC charging or battery inverter discharge.
[24]	The temperature of the main transformer is overheated	Yes	If the internal main transformer temperature is too high, turn off the AC charging or battery inverter discharge.
[25]	Ac input relay short circuit	Yes	Ac input relay short-circuit protection prevents the inverter AC output from being pumped back into the bypass AC input,the inverter is turned off.
[26]	The AC output relay is short-circuit	-	-
[27]	Fan failure	Yes	If the fan is blocked or fails, disable the inverter output and charging functions.
[28]	EEPRO hitch	-	-
[29]	SPICommunication failure	-	-
[30]	Type detectionerror	Yes	The model is not set before delivery, and the model identification is wrong.
[31]	The bus fails to soft	-	-
[32]	The leakage current is abnormal	-	-
[33]	Parallel control can communication is faulty	Yes	In parallel mode, CAN communication is lost, AC output and charging are turned off
[34]	Parallel control can communication is faulty	Yes	In parallel mode, CAN communication is lost, AC output and charging are turned off
[35]	Parallel mode is faulty	Yes	In parallel mode, the system has inconsistent machine parallel mode [31] Settings.
[36]	Parallel current sharing fault	Yes	In parallel mode, the AC output of the battery inverter differs greatly from the non-uniform current output of each machine. Turn off the AC output and charge.

[37]	Parallel ID setting error	Yes	In parallel mode, the RS485 addresses repeatedly conflict. The fault stops the AC output and charge. After the host automatically reallocates the address, the fault is cleared and the host enters the parallel
[38]	Inconsistent Battery in parallel mode	Yes	In parallel mode, the battery voltage input of each machine varies greatly
[39]	Inconsistent AC input source in parallel mode	Yes	Inconsistent AC input source in parallel mode, If in the three-phase mode, the two-phase mains input source is inconsistent, the fault is caused by trying to replace the mains input wiring of any two machines
[40]	The parallel mode synchronization fails	Yes	Parallel mode, hardware synchronization signal reception failure, stop parallel and AC output
[41]	Inconsistent system firmware version in parallel mode	Yes	If the program version is inconsistent in the parallel system, stop the parallel and AC output
[42]	The parallel communication cable is faulty	Yes	The parallel communication line is faulty. Stop the parallel and AC output
[43]	Serial number error	Yes	The serial number is not set before the factory, or the factory serial number is set repeatedly in the system
[49]	BMS communication error	No	Check whether the communication line is connected correctly and whether [11] is set to the corresponding lithium battery communication protocol
[50]	BMS other alarm	No	Check the BMS fault type and troubleshoot lithium battery problems
[51]	BMS battery over temperature alarm	No	BMS alarm lithium battery over temperature
[52]	BMS battery over current alarm	No	BMS alarm lithium battery over current
[53]	BMS battery over voltage alarm	No	BMS alarm lithium battery over voltage
[54]	BMS battery low voltage alarm	No	BMS alarm lithium battery low voltage

[55] BMS battery temperature	. I No	BMS alarm lithium battery low temperature
------------------------------	--------	---

9.2、Trouble Shooting

Fault code	Faults	Handling measures
/	No display on the screen	Check if the battery air switch or the PV air switch has been closed; if the switch is in the "ON" state; press any button on the screen to exit the screen sleep mode.
[06]	Rechargeable battery overvoltage protection	Measure if the battery voltage exceeds rated. If it exceeds, the battery needs to be discharged until the voltage is below the overvoltage recovery point of the battery.
[01] [02]	Battery under voltage protection	Charge the battery until it returns to the low voltage disconnection recovery voltage
[27]	Fan failure	Check if the fan is not turning or blocked by foreign object
[22] [23]	Heat sink over temperature protection	When the temperature of the device is cooled below the recovery temperature, normal charge and discharge control is resumed
[09] [10]	Bypass overload protection, inverter overload protection	1.Reduce the use of power equipment; 2.Restart the unit to resume load output
[11]	Inverter short circuit protection	1.Check the load connection carefully and clear the short-circuit fault points; 2.Re-power up to resume load output
[18]	PV overvoltage	Use a multimeter to check if the PV input voltage exceeds the maximum allowable input voltage rated
[05]	Battery missed alarm	Check if the battery is not connected or if the battery circuit breaker is not closed
[40] [42]	Parallel connection fault	Check whether the parallel line is not connected well, such as loose or wrong connection
[37]	Parallel ID setting error	Check whether the setting of parallel ID number is repeated.
[36]	Parallel current sharing fault	Check whether the parallel current sharing line is not connected well, such as loose or wrong connection

[39]	Inconsistent AC input source in parallel mode	Check whether the parallel AC inputs are from the same input interface.If in the three-phase mode, the two-phase mains input source is inconsistent, the fault is caused by trying to replace the mains input wiring of any two machines
[41]	Inconsistent system firmware version in parallel mode	Check whether the software version of each inverter is consistent

Note: If you encounter a product fault that cannot be solved by the methods in the above table, please contact our after-sales service department for technical support, and do not disassemble the equipment yourself.

10. Protection and Maintenance

10.1、Protections provided

No.	Protections	Description
1	PV current/ power limiting protection	When charging current or power of the PV array configured exceeds the PV rated, it will charge at the rated
2	PV night reverse-current protection	At night, the battery is prevented from discharging through the PV module because the battery voltage is greater than the voltage of PV module
3	Mains input over voltage protection	When the mains voltage exceeds 280V (230V model), the mains charging will be stopped and switched to the inverter mode.
4	Mains input under voltage protection	When the mains voltage is lower than 170V (230V model /UPS mode) or 90V (APL mode), the mains charging will be stopped and switched to the inverter mode.
5	Battery over voltage protection	When the battery voltage reaches the overvoltage disconnection point, the PV and the mains will be automatically stopped to charge the battery to prevent the battery from being overcharged and damaged
6	Battery low voltage protection	When the battery voltage reaches the low voltage disconnection point, the battery discharging will be automatically stopped to prevent the battery from being over-discharged and damaged
7	Load output short circuit protection	When a short circuit fault occurs at the load output terminal for more than 200 milliseconds, the AC output is immediately turned off
8	Heat sink over temperature protection	When the internal temperature is too high, the all-in-one machine will stop charging and discharging; when the temperature returns to normal, charging and discharging will resume
9	Overload protection	Output again 3 minutes after an overload protection, and turn the output off after 5 consecutive times of overload protection until the machine is re-powered. For the specific overload level and duration, refer to the technical parameters table in the manual

10	PV reverse polarity protection	When the PV polarity is reversed, the machine will not be damaged
11	AC reverse protection	Prevent battery inverter AC current from being reversely input to Bypass
12	Bypass over current protection	Built-in AC input overcurrent protection circuit breaker
13	Battery input over current protection	When the discharge output current of the battery is greater than the maximum value and lasts for 1 minute, the AC input would switched to load
14	Battery input protection	When the battery is reversely connected or the inverter is short-circuited, the battery input fuse in the inverter will blow out to prevent the battery from being damaged or causing a fire
15	Charge short protection	When the external battery port is short-circuited in the PV or AC charging state, the inverter will protect and stop the output current
16	CAN communication loss protection	In parallel operation, an alarm will be given when CAN communication is lost
17	Parallel connection error protection	In parallel operation, the equipment will be protected when the parallel line is lost
18	Parallel battery voltage difference protection	In parallel operation, the equipment will be protected when the battery connection is inconsistent and the battery voltage is greatly different from that detected by the host
19	Parallel AC voltage difference protection	In parallel operation, the equipment will be protected when the AC IN input connection is inconsistent
20	Parallel current sharing fault protection	In parallel operation, the running equipment will be protected when the load difference of each inverter is large due to improper connection of current sharing line or device damage
21	Synchronization signal fault protection	The equipment will be protected when there is a fault in the guidance signal between parallel buses, causing inconsistent behavior of each inverter

10.2 Maintenance

In order to maintain the best long-term performance, it is recommended to conduct following checks twice a year.

- 1. Make sure that the airflow around the unit is not blocked and remove any dirt or debris from the heat sink.
- 2. Check that all exposed wires are damaged by exposure to sunlight, friction with other objects around them, dryness, bite by insects or rodents, etc., and the wires shall be repaired or replaced if necessary.
- 3. Verify for the consistency of indication and display with the operation of the device. Please pay attention to the display of any faults or errors, and take corrective actions if necessary.
- 4. Check all wiring terminals for corrosion, insulation damage, signs of high temperature or burning/discoloration, and tighten the screws.
- 5. Check for dirt, nesting insects and corrosion, and clean up as required.
- 6. If the arrester has failed, replace in time to prevent lightning damage to the unit or even other equipment of the user.

The company does not assume any liability for damage caused by:



- a) Improper use or use in improper site.
- b) Open circuit voltage of the PV module exceeds the maximum allowable voltage rated.
- c) Temperature in the operating environment exceeds the limited operating temperature range.
- d) Disassemble and repair the all-in-one solar charge inverter without permission.
- e) Force majeure: Damage that occurs in transportation or handling of the all-in-one solar charge inverter.



Danger of electric shock! When doing the above operations, make sure that all power supplies of the all-in-one machine have been disconnected, and all capacitors have been discharged, and then check or operate accordingly!

11. Technical parameters

	cai parameters
Models	N1F-A6.5US
Parallel mode	
Permitted parallel number	1~6
AC mode	
Rated input voltage	120Vac±5%
Input voltage range	(90Vac-140Vac)±2%
Frequency	50Hz/60Hz (Auto detection)
Frequency Range	47±0.3Hz~55±0.3Hz (50Hz); 57±0.3Hz~65±0.3Hz (60Hz);
Overload/ short circuit protection	Circuit breaker
Efficiency	>95%
Conversion time (bypass and inverter)	10ms (typical)
AC reverse protection	Yes
Maximum bypass phase overload current	60A
Inverter mode	
Output voltage waveform	Pure sine wave
Rated output power (VA)	6500
Rated output power (W)	6500
Power factor	1
Rated output voltage (Vac)	120Vac
Output voltage error	±5%
Output frequency range (Hz)	50Hz±0.3Hz/60Hz±0.3Hz

Maximum Efficiency	>93%
Overload protection	(102% < load <125%) \pm 10%: report error and turn off the output after 5 minutes; (110% < load < 125%) \pm 10%: report error and turn off the output after 10 seconds; Load >125% \pm 10%: report error and turn off the output after 5 seconds;
Peak power	12000VA
Loaded motor capability	5HP
Output short circuit protection	Circuit breaker
Bypass circuit breaker phase specification	63A
Rated battery input voltage	48V (Minimum starting voltage 44V)
Battery voltage range	40.0Vdc~60Vdc±0.6Vdc (Undervoltage alarm/shutdown voltage/overvoltage alarm/overvoltage recovery settable on LCD screen)
Power saving mode self-consump tion	Load≤25W
AC charging	
Battery type	Lead acid or lithium battery
Maximum charge current(can be set)	120A
Charge current error	±5Adc
Charge voltage range	40 -60Vdc
Short circuit protection	Circuit breaker and blown fuse
Circuit breaker phase specifications	63A
PV charging	
Maximum PV open circuit voltage	300Vdc

80Vdc~300Vdc
90Vdc~260Vdc
40-60Vdc
4500W+4500W
22A+22A
0-150A
Blown fuse
Reverse polarity protection
ng Max charger current specifications (AC charger+PV charger)
0-150A
fications
CE(IEC62109-1,2)
EN61000, C2
-15°C to 55°C
-25°C ~ 60°C
5% to 95% (Conformal coating protection)
≤60dB
Forced air cooling, variable speed of fan
USB/RS485(/WiFi/GPRS)/ Dry node control
550mm*365mm*130mm
20